Quick Start for your WS-7013U

Hint: Use good quality Alkaline Batteries and avoid rechargeable batteries.

1. Have the indoor station and outdoor remote 3 to 5 apart.
2. Batteries should be out of both units for 10 minutes.
3. Place the batteries into the **outdoor remote** first then into the indoor station.
   (All outdoor remotes must be started before the indoor station)
4. DO NOT PRESS ANY BUTTONS FOR 10 MINUTES.

In this time the display and sensor will start to talk to each other and the display will show both the indoor temperature and an outdoor temperature. If the station does not display both temperatures after the 10 minutes please retry the set up as stated above. After both indoor and outdoor temperatures are displayed for 10 minutes you can place your sensor outdoors and set your time.

The remote sensor should be placed in a dry, shaded area. The remote sensor has a range of 80 feet. Any walls that the signal will have to pass through will reduce distance. An outdoor wall or window will have 20 to 30 feet of resistance and an interior wall will have 10 to 20 feet of resistance. Your distance plus resistance should not exceed 80 ft. in a straight line.

NOTE: Fog and mist will not harm your remote sensor but direct rain must be avoided.

To complete the set up of your temperature station after the 10 minutes have passed please follow the steps below.

1. Press and hold the SET button for 5 seconds.
   A 12h or 24h will appear on the top line. (12h for AM/PM, 24h for military time)
   a. To change between 12h and 24h press and release the MIN/MAX button.
      When you have your choice shown on the display press and release the SET button once.
2. Degree Fahrenheit will now show.
   a. To change between Fahrenheit and Celsius, press and release the MIN/MAX button.
      When you have your choice shown on the display press and release the SET button once.
3. An hour will now be flashing.
   a. Press and release the MIN/MAX button until the correct hour is shown.

   NOTE: When in the 12h mode there is "PM" displayed under the word TIME when in the PM hours. During the AM hours this area will be blank.

   When the correct hour is shown press and release the SET button once.
4. A minute will now be flashing.
   a. Press and release the MIN/MAX button until the correct minutes are displayed.

   Press and release the SET button once more and you are done.